



Your  
"One Source Solution"  
distributor-manufacturer  
of printer parts & supplies

## HP MAINTENANCE KIT CONTENTS

DESCRIPTION	PART#	QTY	DESCRIPTION	PART#	QTY
<b>II,III/SX MAINTENANCE KIT 100,000 PAGES</b>	<b>33449-67903</b>		<b>5SI,8000/WX MAINTENANCE KIT 350,000 PGS</b>	<b>C3971-67902</b>	
II,III/SX FUSER ASSEMBLY	RG1-0939	1	5SI,8000/WX FUSER ASSEMBLY	RG5-4447	1
II,III/SX SEPARATION PAD	RF1-1145CLN	1	5SI,8000/WX TRANSFER ROLLER	RF5-1412	1
II,III/SX FEED ROLLER ASSEMBLY	RG1-0931	1	5SI,8000/WX SEPARATION FEED ROLLER	RF5-1834	4
II,III/SX TRANSFER CORONA ASSEMBLY	RG1-0933	1	5SI,8000/WX PICKUP ROLLER	RF5-1835	2
II,III/SX FUSER CLEANING PAD	RG1-0966	1			
II,III/SX DELIVERY COUPLER ASSEMBLY	RG1-0967CLN	1	<b>5L MAINTENANCE KIT 50,000 PAGES</b>	<b>H3971-60001</b>	
II,III/SX COOLING FAN	RH7-1122CLN	1	5L FIXING ASSEMBLY	RG5-1964	1
<b>IIP,IIIP/LX MAINTENANCE KIT 100,000 PGS</b>	<b>33481-69007</b>		5L TRANSFER ROLLER	RF5-1534	1
IIP,IIIP/LX FUSER ASSEMBLY	RG1-1788	1	5L PICKUP ROLLER	RG5-3486	1
IIP,IIIP/LX TRANSFER ROLLER	RA1-7627	1	5L SEPARATION PAD	RY7-5077	1
IIP,IIIP/LX PAPER FEED ROLLER	RF1-2394	1	5L IDLER ROLLER	RB1-7226	1
IIP,IIIP/LX SEPARATION PAD	RG1-1912	1			
IIP,IIIP/LX PICKUP ROLLER ASM	RG1-1792	1	<b>6L MAINTENANCE KIT 50,000 PAGES</b>	<b>H3972-60001</b>	
IIP,IIIP/LX FACE DOWN DELIVERY ROLLER	RG1-1791	1	6L FIXING ASSEMBLY	RG5-3439	1
			6L TRANSFER ROLLER	RF5-1534	1
<b>3SI,4SI/NX MAINTENANCE KIT 200,000 PGS</b>	<b>C2062-67901</b>		6L PICKUP ROLLER	RG5-3486	1
3SI,4SI/NX FUSER ASSEMBLY	RG5-0046	1	6L SEPARATION PAD	RY7-5077	1
3SI,4SI/NX TRANSFER ROLLER	RG5-0141	1	6L IDLER ROLLER	RB2-1699	1
3SI,4SI/NX PICKUP ROLLER	RF5-0041	6			
3SI,4SI/NX TRANSFER ROLLER CLIP	RB1-0818	1	<b>5P/VX MAINTENANCE KIT 100,000 PAGES</b>	<b>H3973-60001</b>	
3SI,4SI/NX DUPLEX ROLLER	RF5-0081	1	5P/VX FUSER ASSEMBLY	RG5-1700	1
			5P/VX TRANSFER ROLLER	RF5-1290	1
<b>4,4M/EX MAINTENANCE KIT 200,000 PAGES</b>	<b>C2001-67912</b>		5P/VX TRAY 1 PICKUP ROLLER	RB1-2205	1
4,4M/EX FUSER ASSEMBLY	RG5-0454	1	5P/VX SEPARATION ROLLER	RB1-6332	1
4,4M/EX TRANSFER ROLLER	RF5-0349	1	5P/VX SEPARATION PAD	RF5-0343	1
4,4M/EX PC PICKUP ROLLER	RB1-2126	1			
4,4M/EX MP PICKUP ROLLER	RB1-2127	1	<b>6P/VX MAINTENANCE KIT 100,000 PAGES</b>	<b>H3966-60001</b>	
4,4M/EX LC PICKUP ROLLER	RB1-2632	1	6P/VX FUSER ASSEMBLY	RG5-4110	1
4,4M/EX MP SEPARATION PAD	RF5-0343	1	6P/VX TRANSFER ROLLER	RF5-0596	1
			6P/VX TRAY 1 PICKUP ROLLER	RB1-2205	1
<b>4+,4M+/EX+ MAINTENANCE KIT 200,000 PGS</b>	<b>C2037-69010</b>		6P/VX SEPARATION PAD	RF5-0343	1
4+,4M+/EX+ FUSER ASSEMBLY	RG5-0879	1	6P/VX PICKUP ROLLER	RB1-6332	1
4+,4M+/EX+ TRANSFER ROLLER	RF5-0349	1			
4+,4M+/EX+ MP PICKUP ROLLER	RB1-2127	1	<b>1100/3200 MAINTENANCE KIT</b>	<b>H3965-60001</b>	
4+,4M+/EX+ LC PICKUP ROLLER	RB1-2650	1	<b>(1100 = 50,000 PGS, 3200 = 25,000 PGS)</b>		
4+,4M+/EX+ PC PICKUP ROLLER	RB1-3477	1	1100,3200 FIXING FILM ASSEMBLY	RG5-4589	1
4,4M/EX MP SEPARATION PAD	RF5-0343	1	1100,3200 TRANSFER ROLLER	RG5-4657	1
			1100,3200 PICKUP ROLLER	RB2-4026	1
<b>4V,4MV/BXII MAINTENANCE KIT 200,000 PGS</b>	<b>C3141-69010</b>		1100 SEPARATION PAD	RF5-2886	1
4V,4MV/BXII FUSER ASSEMBLY	RG5-1557	1	3200 SEPARATION PAD	HB1-3035	1
4V,4MV/BXII TRANSFER ROLLER	RG5-1410	1	1100,3200 SEPARATION PAD KIT	RY7-5050	1
4V,4MV/BXII SEPARATION PAD	RF5-0302	1	1100,3200 PRESSURE ROLLER	RF5-2823	1
4V,4MV/BXII MP PICKUP ROLLER	RB1-1411	1	1100,3200 FACE DOWN ROLLER	RF5-2830	1
4V,4MV/BXII OPT. 500 SHEET PICKUP ROLLER	C3760-60506	1			
			<b>2100 MAINTENANCE KIT 150,000 PAGES</b>	<b>H3974-60001</b>	
<b>5,5M,5N/EX+ MAINTENANCE KIT 200,000 PGS</b>	<b>C3916-67901</b>		2100 FUSER ASSEMBLY	RG5-4132	1
5,5M,5N/EX+ FUSER ASSEMBLY	RG5-0879	1	2100 TRANSFER ROLLER	RG5-4164	1
5,5M,5N/EX+ TRANSFER ROLLER	RF5-0349	1	2100 T1 PICKUP ROLLER	RB2-2891	1
5,5M,5N/EX+ TRAY 1 PICKUP ROLLER	RB1-2205	1	2100 T2 & T3 PICKUP ROLLER	RB2-2900	1
5,5M,5N/EX+ MP SEPARATION PAD	RF5-0343	1	2100 T1 SEP PAD	RB2-6348	1
5,5M,5N/EX+ TRAY 2 PICKUP ROLLER	RB1-7911	1	2100 T2 & T3 SEP PAD	RB9-0695	1
5,5M,5N/EX+ TRAY 3 PICKUP ROLLER	RB1-7983	1			



DESCRIPTION	PART#	QTY	DESCRIPTION	PART#	QTY
<b>2200 MAINTENANCE KIT 150,000 PAGES</b>	<b>H3978-60001</b>		<b>5000 MAINTENANCE KIT 150,000 PAGES</b>	<b>C4110-67901</b>	
2200 FUSER ASSEMBLY	RG5-5559	1	5000 FUSER ASSEMBLY	RG5-5455	1
2200 TRANSFER ROLLER	RG5-5581	1	5000 TRANSFER ROLLER	RG5-3579	1
2200 T1 PICKUP ROLLER	RB2-2900	1	5000 LC PICKUP ROLLER	RB1-8865	4
2200 T2 PICKUP ROLLER	RB2-6304	1	5000 TRAY 1 SEP PAD	RF5-3439	1
2200 T1 SEP PAD	RB2-6348	1	5000 SEPARATION PAD WITH SPRING	RG9-1485	2
2200 T2 SEP PAD	RB2-6349	1	5000 TRAY 2 PICKUP ROLLER	RB2-1821	2
			5000 TRAY 1 PICKUP ROLLER	RB2-1820	1
<b>2300 MAINTENANCE KIT 150,000 PAGES</b>	<b>U6180-60001</b>		5000 500 SHEET FEED ROLLER	RF5-2634	2
2300 FUSER ASSEMBLY	RM1-0354	1			
2300 TRANSFER ROLLER	RM1-0343	1	<b>5100 MAINTENANCE KIT 150,000 PAGES</b>	<b>Q1860-67908</b>	
2300 T1 PICKUP ROLLER	RC1-0945	1	5100 FUSER ASSEMBLY	RG5-7060	1
2300 T2 PICKUP ROLLER	RB2-6304	1	5100 TRANSFER ROLLER	RG5-1542	1
2300 T1 SEP PAD	RC1-0939	1	5100 LC PICKUP ROLLER	RB1-8865	4
2300 T2 SEP PAD	RC1-0954	1	5100 TRAY 2 PICKUP ROLLER	RB2-1821	2
			5100 TRAY 1 PICKUP ROLLER	RB2-1820	1
<b>3100/3150 MAINTENANCE KIT 50,000 PGS</b>	<b>H3975-60001</b>		5100 500 SHEET FEED ROLLER	RF5-2634	2
3100,3150 FUSER ASSEMBLY	RG5-4678	1	5100 250 SHEET TRAY SEP PAD	RF5-4120	2
3100,3150 TRANSFER ROLLER	RF5-1534	1	5100 MP SEPARATION PAD	RF5-4119	1
3100,3150 PICKUP ROLLER	RG5-3486	1	5100 CLEANING BRUSH	RB2-1906	1
3100,3150 SEPARATION PAD	RY7-5077	1			
3100,3150 IDLER ROLLER	RB2-1699	1	<b>8100,8150 MAINTENANCE KIT 350,000 PGS</b>	<b>C3914-69001</b>	
3100,3150 PRESSURE ROLLER	RF5-2364	1	8100,8150 FUSER ASSEMBLY	RG5-6532	1
			8100,8150 TRANSFER ROLLER	RF9-1394	1
<b>4000/4050 MAINTENANCE KIT 200,000 PGS</b>	<b>C4118-67902</b>		8100,8150 PICKUP ROLLER	RF5-1834	6
4000/4050 FUSER ASSEMBLY	RG5-2661	1			
4000/4050 TRANSFER ROLLER	RG5-4283	1	<b>9000 MAINTENANCE KIT 350,000 PAGES</b>	<b>C9152A</b>	
4000/4050 SEPARATION FEED ROLLER	RF5-1885	6	9000 FUSER ASSEMBLY	RG5-5750	1
4000/4050 TRAY 1 PICKUP ROLLER	RG5-3718	1	9000 TRANSFER ROLLER ASSEMBLY	RG5-5662	1
			9000 FEED SEPARATION ROLLERS	RF5-3338	7
<b>4100 MAINTENANCE KIT 200,000 PAGES</b>	<b>C8057-67901</b>		9000 PICKUP ROLLERS	RF5-3340	2
4100 FUSER ASSEMBLY	RG5-5063	1			
4100 TRANSFER ROLLER	RG5-5295	1			
4100 SEPARATION FEED ROLLER	RF5-3114	6			
4100 TRAY 1 PICKUP ROLLER	RG5-3718	1			
<b>4200 MAINTENANCE KIT 200,000 PAGES</b>	<b>Q2429-67902</b>				
4200 FUSER ASSEMBLY	RM1-0013	1			
4200 TRANSFER ROLLER	RM1-0699	1			
4200 FEED-SEP ROLLER TRAY 1	RL1-0019	1			
4200 PICKUP ROLLER TRAY 2	RM1-0036	3			
4200 FEED-SEP ROLLER TRAY 2	RM1-0037	3			
<b>4300 MAINTENANCE KIT 200,000 PAGES</b>	<b>Q2436-67901</b>				
4300 FUSER ASSEMBLY	RM1-0101	1			
4300 TRANSFER ROLLER	RM1-0699	1			
4300 FEED-SEP ROLLER TRAY 1	RL1-0019	1			
4300 PICKUP ROLLER TRAY 2	RM1-0036	3			
4300 FEED-SEP ROLLER TRAY 2	RM1-0037	3			

### HP COLOR LASER PRINTERS

<b>4500 MAINTENANCE KIT 50,000 PAGES</b>	<b>C4197A</b>	
4500 FUSER ASSEMBLY	RG5-5154	1
4500 AIR FILTER, LARGE	RB2-1282	1
4500 AIR FILTER, SMALL	RB2-1283	1
4500 PICKUP ROLLER	RF5-1885	4
<b>8500 MAINTENANCE KIT 50,000 PAGES</b>	<b>C4155A</b>	
8500 FUSER ASSEMBLY	RG5-3060	1
8500 FEED SEPARATION ROLLERS	RF5-1834	6